Take control of your concrete.



Our Non-Chloride Accelerator and Mini Delayed Set are invaluable to control concrete set time.



For flawless slabs, use Fritz-Pak's Superplasticizers added directly to the truck at the job site. Never weaken your concrete with water to get the slump you need.





Use **Control Finish** to complete the job. It "brings up the butter" to allow finishing without re-tempering with water, for a smooth durable surface.

Excellent preparation for stamping and stenciling.

For countertops or precast, use **Counter-Flo** to get exactly the flow you need without more water, and without using someone else's expensive one-size fits-all mix. Our mini bags of white retarder and accelerator are perfect for small decorative batches.



Call Today 888-746-4116, or visit our website www.fritzpak.com to see our complete product line.